

# Alcolizer

## HH3 alcohol tester

Developed for small to medium-sized enterprises, the Alcolizer HH3 is outstanding value and ideal for companies starting workplace alcohol testing.

### INDUSTRIAL GRADE HANDHELD ALCOHOL TESTER

- › Rugged and proven to perform Multi-function testing
- › USB data download
- › Simple, easy to use menu screens
- › Outstanding value, entry level instrument

### PROVEN PERFORMANCE, HIGH GRADE

The Alcolizer HH3 has a highly responsive platinum electrochemical fuel cell that delivers capable, fast and accurate results in both commercial and industrial applications.

### MULTI-FUNCTION TESTING

Performs both Standard Mouthpiece and Passive tests to suit any workplace and Drug and Alcohol testing program.

### DURABLE AND CAPABLE

Developed for heavy duty conditions, the Alcolizer HH3 has a robust, shock resistant casing delivering durability and reliability in commercial, industrial and remote environments.

### SERVICE AND SUPPORT

Each HH3 Alcohol Tester is backed by a 36 month warranty.

### CALIBRATION

HH3 requires calibration every twelve months as per Australian Standards Certification requirement. HH3 will display a warning message after switch on if 28 days or less remain before calibration is required.



### STANDARD FEATURES

- › Multi-function capability for both Standard Mouthpiece and Passive testing
- › Highly responsive, law enforcement grade platinum electrochemical fuel cell
- › Data download of 30,000+ logs
- › Unlimited tests
- › Multi-language capability
- › Transreflective mono screen
- › 36 month warranty
- › AC/DC charger
- › USB data download cable
- › Proudly designed, developed and made in Australia by Alcolizer Technology to AS3547:2019 Certification Type 2.

HH3 Product Code: 444-300075

### Contact Us

Phone 1800 069 161 | Email [info@pathtech.com.au](mailto:info@pathtech.com.au)

[pathtech.com.au](http://pathtech.com.au)

## TECHNICAL SPECIFICATIONS

Instrument Application	Commercial and Industry
Sensor Type	Law enforcement grade, highly responsive platinum electrochemical fuel cell
Accuracy	As per Australian Standard AS3547:2019
BrAC Range	0.000 – 0.462g/210L (BrAC) result
Test Time	Within 3-5 seconds for a 0.100% BrAC result
Recovery Time	Instant for 0.000 BrAC readings (retained on-screen for 10 seconds)
Display	Transreflective mono graphics screen display
Mouthpiece	Standard spigot locator or non-return valve
Calibration	Every 12 months
Operating Temperature	Range -5°C to 55°C
Power supply	Rechargeable Li-Ion battery system
Weight	272g (including battery)
Dimensions	202mm H x 63mm W x 39mm D

### Other Breathalysers available from Pathtech:



**HH4 Alcohol tester**  
Advanced industry handheld alcohol tester



**LE5 Alcohol tester**  
Law Enforcement Grade



**Centurion Quantum Wall Mounted Breathalyser**

Pathtech offers training on all of our Alcohol Breathalysers either in person or virtually. Contact us today to discuss your training requirements.

#### Contact Us

Phone 1800 069 161 | Email [info@pathtech.com.au](mailto:info@pathtech.com.au)

[pathtech.com.au](http://pathtech.com.au)



**Pathtech**  
First Choice In Science