

# Alcolizer

## HH4 alcohol tester

The advanced performance and features benefit organisations who need a comprehensive alcohol testing instrument.

### ADVANCED INDUSTRY HANDHELD ALCOHOL TESTER

- › Advanced functionality with colour screen
- › Industrial grade alcohol tester, robust and reliable
- › Mouthpiece and passive testing with data download
- › Bluetooth connectivity standard

### ADVANCED PERFORMANCE, LAW ENFORCEMENT GRADE

The Alcolizer HH4 has a highly responsive platinum electrochemical fuel cell that delivers capable, fast and accurate results in both heavy industry and law enforcement applications.

### MULTI-FUNCTION TESTING

Performs both Active (mouthpiece) and Passive tests to suit any workplace Drug and Alcohol testing program. Alcolizer HH4 offers the latest of Alcolizer's technology advancements – Pressure-Activated Passive Testing and Fast-Passive Testing. Pressure-Activated is automatically activated by breath pressure provided by a test subject. Fast-Passive is a new, faster response time for Passive Testing.

### DURABLE AND CAPABLE

Developed for heavy duty conditions, the Alcolizer HH4 has a robust, shock resistant casing delivering durability and reliability in commercial, industrial and remote environments.

### SERVICE AND SUPPORT

Each HH4 Alcohol Tester is backed by a 36 month warranty and is supported by the AlcoCARE™ program. Our global network of service providers and factory trained technicians provides rapid return calibration and expert customer support.



### STANDARD FEATURES

- › Multi-function capability for both Active (Standard) mouthpiece and Passive testing
- › Highly responsive, law enforcement grade platinum electrochemical fuel cell
- › Data download of 30,000+ logs
- › Unlimited tests
- › Transreflective colour LCD screen
- › Bluetooth data capability
- › USB data download cable
- › Multi-language capability
- › 36 month warranty
- › Designed, developed to AS3547 Certification Type 2
- › AC/DC charger plus vehicle charger
- › Soft shoulder bag
- › Wrist lanyard

HH4 Product Code: 444-300115

#### Contact Us

Phone 1800 069 161 | Email [info@pathtech.com.au](mailto:info@pathtech.com.au)

[pathtech.com.au](http://pathtech.com.au)

## TECHNICAL SPECIFICATIONS

Instrument Application	Commercial and Industry
Sensor Type	Law enforcement grade, highly responsive
platinum electrochemical fuel cell	As per Australian Standard AS3547:2019
Accuracy	As per Australian Standard AS3547:2019
BrAC Range	0.000 – 0.462g/210L (BrAC) result
Test Time	Within 3-5 seconds for a 0.100% BrAC result
Recovery Time	Instant for 0.000 BrAC readings (retained on-screen for 5 seconds)
Display	Transreflective colour graphics LCD screen
Mouthpiece	Standard spigot locator or non-return valve
Calibration	Every 12 months
Operating Temperature	Range -5°C to 55°C
Power supply	Rechargeable Li-Ion battery system
Weight	272g (including battery)
Dimensions	202mm H x 63mm W x 39mm D

### Other Breathalysers available from Pathtech:



**HH3 Alcohol tester**  
Advanced industry handheld  
alcohol tester



**LE5 Alcohol tester**  
Law Enforcement Grade



**Centurion Quantum Wall  
Mounted Breathalyser**

Pathtech offers training on all of our Alcohol Breathalysers either in person or virtually. Contact us today to discuss your training requirements.